

MANUAL AND PATTERN REVISIONS

In any instructions Manual there will be the inevitable changes and updates as the program matures. For this reason we are providing this page for recording these updates, and respectfully advise the builder to keep this record up to date. Some of the updates will include new pages to be inserted into the manual, and many will just list areas where revisions will be pencilled in. Enter the revision number and date on this page, make the describe revisions, and then insert the revision letter in the book behind this page.

Kit No. _____ **Shipped date** _____

Rev No.	Date	Comments or Description
1	2/04/92	Replace Rudder Section pages 1,2,3,5,6,7.
2	4/02/92	3 View Drawing, Technical Specs. (Prelim).
3	4/28/92	Replace Wing Section. Ailerons pages 3 and 6.
4	5/27/92	Replace Table of Contents, Procedures and Fuselage Sections in entirety. Replace Wing pages 5,22,30; discard page 31; Renumber old pages 32 to 31; Add new page 32. Replace Ailerons and Flaps pages 2,13,14.
5	8/13/92	Replace "Kis Technical Specifications" pages 1 and 2; Replace listing of parts with "Kis packing List"; Replace pages 14 of "Horizontal Stabiliser and Elevator"; Replace pages 17 and 21 and 32 of "Construction of the Wing"; Add new Section "Airframe Assembly"; Add new section "Instruments and Electrical"; Replace "Weight and Balance" Section.
6	8/24/92	Replace "Horizontal Stabiliser and Elevator" page 3. Replace "Fuselage" Section 3 page 8.
7	12/2/92	Replace Section 3 Fuselage in its entirety (New Section dated Nov. 6, 1992). Replace page Fuselage 1-5 and Fuselage 2-8. Replace original pattern sheet #1 Rev. "A" version of sheet.
8	12/4/92	Note: (This Revision applies <u>ONLY</u> to kits shipped on or after 12/1/92. Replace "Wing Section" pages 10 and 11. Add page 11A. Replace pages 15,28,29.
9	12/19/92	Add new Section "Firewall Forward" (pages 1 through 5). Replace "Stab and Elevator" page 19, "Fuselage" second section pages 2-8 and 2-9, "Elevator" page 9. Replace "Fuselage" First section page 1-18.
10	1/07/93	Replace "Stab and Elevator" page 16.

- | | | |
|----|-----------|---|
| 11 | 1/09/93 | Note: (This revision applies <u>ONLY</u> to kits shipped after 1/15/93). Remove "Stab and Elevator" pages 9 through 20. Install new pages 9 through 19. |
| 12 | 2/03/93 | Add new section "Finish and Upholstery". Replace "Wing" page 14 and 15. Replace "Fuselage" pages 1-16, 1-17, 1-18, and 1-19. |
| 13 | 5/26/93 | Add new section "Fuselage" Fourth Section (7) pages. Replace "Fuselage" 1-11 corrected figure, "Fuselage" 2-10 corrected figure-dimension added for Fuselage stick assembly brackets. "Fuselage" 3-5 corrected figure-bulkhead references. |
| 14 | 1/18/94 | Remove Rudder page 6, Replace with revised Rudder page 6. |
| 15 | 12/22/94 | Replace table of contents page 2. add new page 3. Replace rudder pages 1, 3, 5, 6, 7, and 8. Replace Ailerons pages 6 and 7. Replace Flap pages 12, 14, and 16. Replace Elevator pages 10, 14,18 and add new pages 20 and 21. Add new page 7 to Airframe Assembly. Renumber 7, 8, 9 and 10. |
| 16 | 1/7/95 | Replace Rudder page 2 , Flap page 16, Elevator page 20. Add Airframe Assembly pages 12 through 15. |
| 17 | 1712/7/95 | Replace Aileron / Flap pages 1 through 6. Replace page 13. |

Table Of Contents

1. INTRODUCTION
2. SPECIFICATIONS
 - Three View
 - Specification Table
 - Parts
3. SHOP AND TOOLS
4. PROCEDURES
 - Health and Safety in Handling Composites
 - Composite Terms and Procedures
 - Aircraft Dimension System
5. HORIZONTAL STABILIZER AND ELEVATOR
 - Construction of the Horizontal Stabiliser Construction of the Elevator
 - Hinging the Stabiliser to the Elevator
6. FUSELAGE
 - First Section
 - Fuselage Moulded Components
 - Reinforcement Patches and Hard Points
 - Levelling and Fixturing
 - Temporary Fitting of the Fuselage Top
 - Firewall
 - Engine Mount Reinforcements
 - Added Reinforcing in the Firewall Area
 - Station 153 Bulkhead
 - Station 189.5 Bulkhead
 - Spar Box
 - Rear Spar
 - Spar Positioning Jig
 - Main Gear Box Reinforcement
 - Second Section
 - Front Floor Assembly
 - Hard Point for the Pushrod Bellcrank
 - Idler Bellcrank
 - Seat Back Assembly
 - Tail Post
 - Horizontal Stabiliser
 - Stick Linkage Assembly
 - Flap Handle Assembly Bracket
 - Control Console - Seat Area

Third Section

Flap Actuation Torque Tube Installation
Installation of Fuselage Top
Fin Right Half Installation
Routing Rudder Cables and Installing Fairleads
Install Left Fin Half
Hanging and Rigging Rudder
Control Tunnel - Baggage Area
Baggage Area Back Panel
Main Gear Installation
Fire Wall Fire Shield Assembly
Nose Gear Assembly
Door Inner Panels
Mount Doors
Instrument Panel
Windshield

7. RUDDER
8. CONSTRUCTION OF THE WING
 - Fabricating the Wing Cradles
 - Building the Wing - Standard Tanks
 - Building the Wing - Large Tanks
9. AILERONS AND FLAPS
 - Construction of the Ailerons
 - Construction of the Flaps
10. AIRFRAME ASSEMBLY
 - Mounting Wing
 - Fabrication and Installation of Control Tubes
 - Fabrication and Installation of Flap Links
 - Fuel System
 - Wing to Fuselage Fairings
 - Wing Tip Installation
11. FIREWALL FORWARD
 - General
 - Motor Mount and Motor Installation
 - Fitting the Cowling and Spinner
 - Propeller
12. INSTRUMENTS AND ELECTRICAL
 - General
 - Battery Installation
 - Instrument Panel
 - Radios
 - Electrical and Wiring
 - Placards
13. FINISHING AND UPHOLSTERY
 - General
 - Preparation and Filling

Painting
Upholstery

14. WEIGHT AND BALANCE
 - General
 - Limitations
 - Weighing
 - Geometric Measurements
 - Calculating the Center of Gravity
15. COCKPIT PROCEDURES
16. LICENSING AND TESTING
 - General
 - Ground Preparations and Tests
 - Taxi Testing Suggestions
 - Flight Testing