


WESTACH
Dual Voltage /
Current
Hobbs Meter)



VT 330	Red	WESTACH Volts + (Terminal 4)
VT 331	Green	WESTACH Volts - (Terminal 5)
AMP 332	White	WESTACH Amps Terminal 3
AMP 333	Black	WESTACH Amps Terminal 1
AMPS 332	White	Amps Shunt 3 (Probe)
AMPS 333	Black	Amps Shunt 1 (Probe)
HB 340	Red	WESTACH Hobbs Supply Terminal 3
HB 341	Black	WESTACH Hobbs Ground Terminal 5
HBS 340	White/Black	Hobbs Power in
HBS 341	White/Red	Hobbs Ground data In (Probe)